

Wire colours

Bl	Blue	Li	Purple
Br	Brown	Ws	White
Ge	Yellow	Or	Orange
Gr	Grey	Ro	Red
Gn	Green	Sw	Black

* Estate models

Key to items

- | | | | |
|----|-------------------------------------|----|---------------------------------------|
| 1 | Battery | 73 | RH rear door control unit |
| 2 | Ignition switch | 74 | Driver's door window switch |
| 5 | Passenger compartment fusebox | a | = switch illumination |
| 6 | Relay plate | g | = interior locking switch |
| 17 | Battery fuseholder | 80 | Central locking warning light |
| 42 | Convenience system control unit | 81 | Driver's door lock |
| 70 | Driver's door control unit | 82 | Driver's door courtesy light |
| 71 | Front passenger's door control unit | 83 | Front passenger's door lock |
| 72 | LH rear door control unit | 84 | Front passenger's door courtesy light |

Diagram 8

H33338

